

ACCESS OPTIONS AND ACCESSORIES

Make sure you design your battery charging procedure as efficient as possible



ACCESS BMU

The Access BMU Battery Monitoring Unit is mounted onto the battery, normally over its entire lifetime. It measures current, voltage, voltage balance between cell groups, temperature, electrolyte level and indicate State of Charge. The Access BMU communicates with any other Access compatible unit via radio. It can for example be set to tell a specific charger which charging parameters to use.

The temperature monitoring is a mandatory input for fast and opportunity charging. The BMU creates statistical information, that are accessible from anywhere using the GET Cloud or on site through your smartphone or PC.

ACCESS BLU

The Access BLU Battery Logging Unit is easily connected to your battery and will measure both charging and discharging by switching between vehicle and charger. The unit communicates with your Access Service Tool and can be set on History log, Event log, Instant log or Momentary value display on computer screen. If the vehicle is on battery replacement operation, the Access BLU will continuously be connected to the vehicle and switch the other end between the batteries.

ACCESS SERVICE TOOL

Access Service Tool is your link between any compatible Access component and your laptop. Linked on radio, the Access Service Tool downloads data from BMUs, BLUs and chargers. It generates relevant individual or fleet reports. Upgrade and upload all information through our the GET Cloud and connect from any mobile or computer at any time.

STANDS

Our stands fit all Micropower chargers. The stands are available in two models, one bench and one floor stand.

CAN-BUS

The CAN-bus communication makes the charger very versatile and adds the possibility to communicate with other systems also using CAN-bus.

I/O-CARD

I/O cards can be equipped with up to 5 individual relays and can be used to control various functions such as an external LED-indicator, stacking beacon for charger status and remote start.

AIR PUMPS

An alternative to ionic mixing where air bubbles are used to mix the battery acid. The air pump is fully integrated in the charger.



ACCESS BATTERY CHARGER

ENERGY EFFICIENT WITH WIRELESS COMMUNICATION



MICROPOWER GROUP
POWERFUL SOLUTIONS PARTNER

ACCESS
MICROPOWER GROUP

Micropower Group AB
Idavägen 1
SE-352 46 Växjö, Sweden
Phone: +46 (0)470 727 400
sales@micropower.se
www.micropower-group.com

CHARGERS FOR EVERY NEED

– ready to network and report

ACCESS 30
MICROPOWER GROUP



ACCESS 32
MICROPOWER GROUP



ACCESS 50
MICROPOWER GROUP



ACCESS 80
MICROPOWER GROUP



ACCESS 100
MICROPOWER GROUP



ACCESS 130
MICROPOWER GROUP



ACCESS 200
MICROPOWER GROUP



ACCESS 260
MICROPOWER GROUP



ACCESS 400
MICROPOWER GROUP



Module assemblies of Access 100-units.
Example: 80V 400A

ACCESS chargers

- High frequency technology
- BBC Best Battery Choice software built-in
- High efficiency
- Algorithms included for most batteries and needs
- Default charging curve with ionic mixing
- Suitable for AGV and fast/opportunity charging, see separate brochures
- Wireless communication
- Available for various mains voltages
- DPL Dynamic Power Limitation function built-in to monitor and cut power peaks
- Compatible with the GET system

* IP54 on data plate requires fixed primary cable

Optimize your battery and charger fleet



Batteries always fully charged with BBC

Create a battery exchange system using the Micropower Access chargers. The chargers interact with each other to determine which battery is the most suitable pick at the moment. Micropower’s Best Battery Charge help you get the most out of your batteries.

Get Ready

GET let you handle installation, service and support of your battery and charger fleets in the most efficient, simple and intelligent way. Being in control has never been easier. The GET system collects data from all your units, analysis it and help you improve your operations and save money. Create a customized dashboard, showing you what you really want to know and let the system send you notifications if anything deviates from your targets.

Real time data transfer, remote service functions and intelligent data analysis customized for you. The GET system continuously uploads data to the cloud, letting you access it from anywhere, through your cell phone, laptop or tablet.

Which ACCESS charger size do you need?

Check out our battery charger guide on our website. You will need mains voltage, battery voltage, battery capacity in Ah, type of battery, and available charging time.

PRODUCT PRIMARY VOLTAGE VAC

	1x200-240	3X200-240	3x380-415	3X440	3x480	3X600
ACCESS 30	24V/40-100A 36V/22-53A 48V/20-60A					
ACCESS 32	24V/60-120A 36V/80A 48V/40-60A					
ACCESS 50		24V/80-130A 36V/60-105A 48V/60-80A	24V/80-130A 36V/60-105A 48V/60-80A	24V/80-130A 36V/60-105A 48V/60-80A	24V/80-130A 36V/60-105A 48V/60-80A	
ACCESS 80			36V/130A 48V/100-130A 80V/60-80A	36V/130A 48V/100-130A 80V/60-80A		
ACCESS 100		24V/150-170A 36V/130-170A 48V/100-130A 80V/80A	24V/150-200A 36V/130-200A 48V/100-165A 80V/80-100A	24V/150A 36V/130-200A 48V/100-165A 80V/60-100A	24V/170A 36V/130-220A 48V/100-165 80V/80-100A	36V/220A 48V/165A 80V/100A
ACCESS 130		24V/300A 36V/300A 48V/220A 80V/130A 120V/90A	24V/300A 36V/300A 48V/220A 80V/130A 120V/90A	36V/300A 48V/220A 80V/130A 120V/90A		
ACCESS 200		24V/300A	24V/300-400A			
		36V/300-340A 48V/200-260A 80/120-160A	36V/300A 48V/200-330A 80V/120-200A	36V/400A 48V/200-260A 80V/160-200A	36V/340-420A 48V/260-330A 80V/160-200A	36V/420A 48V/330A 80V/200A
ACCESS 260		80V/260A	80V/260A 120V/180A	80V/260A 120V/180A	120V/180A	
ACCESS 400			36V/400-600A 48V/330-660A 80V/200-600A 120V/180-720A	36V/400-600A 48V/330-660A 80V/200-600A 120V/180-720A		